

Terra Prime - Quick Manual

<https://www.terrapavetech.com/terrapavetech/tp.html>

Versatile Application:



- **Spray rate** (TPRime + H₂O) = 0.36 **gal/yd²** or 1.63 liter/m²
- **Concentration** = 1 **gallon** TPRime / 8.5 **gallons** H₂O or 1 liter TPRime / 8.5 liter H₂O
(mix concentrate before use with water H₂O)
- **Final Residual** = 0.04 **gallons of** Terra Prime **per yd²...** or 0.18 liter/m²
(Let TPRime cured for 4 hours before ASPHALT application)



We strongly recommend using Terra Pave White for the base stabilization before using Terra Prime for the prime coat for Asphalt application on top.

<https://www.terrapavetech.com/terrapavetech/tpw.html>